

# 30W Gobo Projector User Manual




## Specification

Item	LED Gobo Projector
Power	30W
Input	AC85~265V
LED Chip	Osram
Angle	15/30/50 degree
IP Rank	IP20/IP65
Projection Distance	3~30m(10~100ft)
Lamp Size	200x100x165mm
Gobo Spec	OD:37mm;ID:23mm
N.W	1.2KG

## CAUTION



## Image Size Against Projection Distance



## Installation Guide



1. install screws to fix the projector



2. Power On.



3. Adjust the image definition by rotating the zoom lens

## Change Gobo



1. Power off; depart the male & female cable



2. Use the hexagon wrench to loosen screw; then take out the heat sink



3. Loosen the jump spring and take out the old glass gobo



4. Install the new glass gobo (vertical direction upside down) then fix the jump spring



5. Install the heat sink into the projector and fasten the screw



6. Connect the male & female cable

## Adjust Image Size



1. Screw out the zoom lens



2. Rotate the optical lens by anticlockwise  
Effect: Image Bigger



3. Rotate the optical lens by clockwise  
Effect: Image Smaller



4. Screw in the zoom lens



Effect at the same distance