

# 60W Gobo Projector User Manual



## Specification

Item	LED Gobo Projector
Power	60W
Input	AC85~265V
LED Chip	Osram
Angle	15° /30° /50°
IP Rank	Ip65
Projection Distance	3~80m(10~265ft)
Lamp Size	270x165x140mm
Gobo Spec	OD:37mm;ID:23mm
N.W	2.7KG

## CAUTION




⚠ Rubber ring didn't attach well



✓ Rubber ring attached well

## Image Size Against Projection Distance



## Changing Glass



Power off & Pull up waterproof male & female cable



Loosen 4 pcs screws & take apart the heat sink



Take out the old gobo & bring the new gobo, keep the back side up



Put the new gobo and fix the jump ring



Put the heat sink back and fasten the 4 pcs screws



Connect the male and female cable and power on

## Adjust Image Definition



Fix the lamp at a proper projection place (image maybe a little misty) & Adjust image size and definition



Screw out the waterproof ring & Screw the front lens to adjust image size



1. Screw out the ring on the front lens to adjust image
2. After focus, screw in the ring to fix the front lens



1. Fix the waterproof rubber ring
2. Ensure the waterproof ring and rubber ring attach tightly (ensure waterproof)



1. Inner zoom lens to adjust image size
2. Outer zoom lens to adjust image definition



## CAUTION

1. waterproof ring and rubber ring should be attached tightly
2. Ensure waterproof ring attach tightly to the lamp body
3. Don't soak the whole lamp into water

## Remote Controller

