


400W Multi-Gobo Switching User Manual




Specification

| Item | LED Gobo Projector |
|---------------------|--------------------|
| Power | 400W |
| Input | AC85~265V |
| LED Chip | Osram |
| Angle | 15°/30°/50° |
| Gobo Qty | 1-9 Gobos |
| Projection Distance | 3~200m(10~660ft) |
| IP Rank | Ip65 |
| Lamp Size | 300x250x221mm |
| Gobo Spec | OD:30mm;ID:20mm |
| N.W | 8.8KG |

CAUTION




⚠ Rubber ring didn't attach well



✓ Rubber ring attached well

Attention: After Focus;the rubber ring & waterproof ring should attach tightly!

Image Size Against Projection Distance



Installation Guide



1. Install screws to fix the projector



2. Power On



3. Adjust the image definition by rotating the zoom lens

Change Gobo



1. Power Off



2. Loosen the screws and take out the heat sink



3. take out the old gobo and install the new gobo
(Right side face bottom)



4. New gobo face the hole of the second layer





4. Fix the heat sink onto the lamp body & fasten the screws

CAUTION

The first layer cannot be rotated by anti-clockwise

Remote Controller

Turn to next gobo



Lamp On

Lamp Off

Stop Changing Gobo

Set Changing Period

For Intelligent Gobo Projector Only

